

NON SLIP PAINT APPLICATION GUIDE

General Notes

- Ensure to read the TECHNICAL DATA SHEET, the PREPARATION GUIDE and the APPLICATION INSTRUCTIONS thoroughly first.
- It is recommended to do a test patch first to determine the suitability of the product.
- Do not apply when the ambient temperature is below 15c or above 28c.
- The substrate must be cool to touch before applying any sealer or coating.
- Always follow the manufacturer's guidelines for coverage.

Application

- Prime the substrate 1st with [Aqua Prime](#) (see application instructions).
- Ensure to apply Non Slip Paint within 12hrs of the application Aqua Prime.
- Non Slip Paint should be applied using a 10mm - 12mm nap roller.
- Thoroughly stir the contents of the bucket whilst adding the colour pack prior to application.
- If using multiple batches:
 - Make a line on the outside of the bucket where it is filled to (after batching you will fill each bucket back up to this line)
 - After adding the colour pack to each batch, pour 1/4 of each batch into a clean bucket and mix them all together. Repeat this process back and forth until all batches are a uniform colour.
 - Note: Do **NOT** mix just 1 batch at a time and then apply as you will get a colour variance.
 - After the product has been "batched together" fill each original bucket back up to the line previously drawn and then thin with 5% water. Mix again thoroughly. Your batches are now ready for application and should be a consistent colour. If they are not, then repeat the above process.
- Ensure to keep wet edge when rolling to avoid roller and lap marks.
- Never apply in direct sunlight or when temperatures exceed 28c
- Allow 24 hours to dry before applying the top coats.
- Apply two coats of [Clear Concrete Sealer](#) (see application instruction).
- Do not walk on for 24 hours and do not drive on for a minimum of 5 days.